



# Converting Tips for Thin Film Liners

## Finishing

- > Rewind and slit rolls immediately after printing to reduce the impact of web tension and heat from the press.
- > Razor knives work well for slitting thin film liners. Knives should be clean and sharp to prevent the edge of the finished web from being nicked.
- > Rewind tension should start between 0.5 and 1.0 pli for die cut labels, with tension gradually decreasing from the start to the end of the roll.
- > Finished rolls should be loose enough to allow for easy, fluid motion near the core when pushing on the side of the roll.
- > Do not use rewinding tables or slitting equipment without taper tension capability.

Visit [www.label.averydennison.com](http://www.label.averydennison.com) for our warranty statement and terms and conditions.

1815, 10/13, PDF

©2013 Avery Dennison Corporation. All rights reserved. Fasson, and all other Avery brands, product names, codes and service program terms are trademarks of Avery Dennison Corporation.



Label and  
Packaging Materials

**Asia Pacific**  
32/F., Skyline Tower  
39 Wang Kwong Road  
Kowloon Bay,  
Kowloon, Hong Kong  
+852 2802-9618

**Europe**  
Lammenschansweg 140  
2321 JX Leiden  
The Netherlands  
+31 71/579-4100

**Latin America**  
Rodovia Vinhedo-  
Viracopos, KM 77  
CEP 13280-000  
Vinhedo - SP, Brazil  
+55 19 3876-7600

**North America**  
8080 Norton Parkway  
Mentor, OH 44060  
800.944.8511